

Operations and maintenance

guide for DAMPA steel- and aluminium ceilings

Inspection instructions

There are no supplier requirements for regular inspection.

Maintenance instructions

The ceiling can be wiped with a soft cloth or vacuumed with a soft nozzle brush.

To wash the ceiling, a regular mild household detergent can be recommended. The soap solution is applied to the ceiling with a natural sponge and is wiped off the ceiling with a soft cotton cloth wrung in clean water.

For particularly greasy surfaces an ammonia-containing detergent can be used.

It cannot be recommended to use scouring agents or cleaning products with a low PH-value for steel ceilings.

In areas with a high humidity and frequent cleaning, ceilings with a special surface coating are recommended.

Demounting and remounting instructions

This should normally only be done by trained personnel according to DAMPA's installation guide for the product.

For tiles in a concealed suspension system the first tile is demounted by inserting DAMPA's dismantling tool in the joint across the direction of the bars, close to a corner and carefully pull downwards.

For tiles longer than 600 mm, there should be two persons doing the demounting to avoid that the tile is twisted out of the suspension system (it needs to be vertically removed from the suspension system).

When the tile is mounted again, it needs to be pressed into the suspension system.

To avoid contaminating the ceiling surface it is recommended to use cotton gloves.

For DAMPA 10/100/200/300 a panel is demounted by pushing it out of the clip while simultaneously pushing opposite on the element there is pulled against.

Be aware of compliance with current work health and safety regulations when cleaning, and de- or remounting.



*Dismantling tool
can be ordered at
our customer service*

**For more information, contact DAMPA customer service at
telephone : +45 6376 1300 or mail dampa@dampa.dk**

DAMPA®